

[Click here to come back to the previous page](#)

input3d.dat

```
=====
=====
=====
=====

      MAIN INPUT DATA FILE : 2D CHANNEL FLOW WITH A SQUARE BAR
(OBSTACLE)

      INCOMPRESSIBLE FLOW
      HEATED SQUARE BAR AT TEMPERATURE Th
= 2.Tc

      OTHER WALLS AT Tc
      TEMPERATURE OF THE INFLOW : Tc
      GRAVITY & BUOYANCY ARE NEGLECTED

      DIMENSIONLESS LAYOUT :

      Length scale      : h (the channel height)
      Reynolds number   Re_h= rho_0.U_0.h/nu= 100

      dimensionless quantities :
      velocity U*       = U/U_0
      temperature T*= T/T0      with T0= Tc ---> Tc*= 1 and
Th*= 2
      kinetic viscosity= 1/Re_h

      dimensionless domain : Lx/h= 10

      Initialisation = uniform velocity field
      inlet flowrate = uniform profil

      Tc
-----
|Th|
|__|
---> inflow          outflow --->
(Tc)                         I

-----
Tc
J
^
|
|
---> I
=====
```

```
=====
&Version File_Version="VERSION2.0"/
+++++++++++++++++++++++++++++
+++++
      GENERAL LAYOUT
      (DIMENSIONLESS)
+++++++++++++++++++++++++++++
+++++
&Fluid_Properties   Reference_Dynamic_Viscosity = 1.00D-02,
Reference_Density= 1.0 ,
                  Heat_Transfer_Flow = .true.,
Reference_Temperature= 1.0, Prandtl = 0.71 /
&Velocity_Initialization I_Velocity_Reference_Value = 1.0 ,
J_Velocity_Reference_Value = 0.0 , K_Velocity_Reference_Value = 0.0 /
=====
=====

      DOMAIN FEATURES
      (DIMENSIONLESS)
=====

=====

&Domain_Features Start_Coordinate_I_Direction= 0.00 ,
End_Coordinate_I_Direction= 10.00 ,
                  Start_Coordinate_J_Direction= 0.00 ,
End_Coordinate_J_Direction= 1.00 ,
                  Start_Coordinate_K_Direction= 0.00 ,
End_Coordinate_K_Direction= 0.00 ,
                  Cells_Number_I_Direction= 256
,Cells_Number_J_Direction= 64 ,Cells_Number_K_Direction= 1,
                  Regular_Mesh= .true. /



-----  

      GEOMETRY OF THE IMMersed BODIES
-----  
  

First (and unic) immersed body (temperature Th= 2.Tc)

&Polyhedral_Immersed_Bodies  Xi_1= 4.5 , Xj_1= 0.5 ,Xk_1= 0.0 , Xi_2=
5.5 , Xj_2= 0.5 ,Xk_2= 0.0 ,
                  Xi_3= 5.5 , Xj_3= 1.0 ,Xk_3= 0.0 , Xi_4=
4.5 , Xj_4= 1.0 ,Xk_4= 0.0 ,
                  Wall_BC_DataSetName ="Set2" /

+++++++++++++++++++
+++++
      DEFINITION OF BOUNDARY CONDITIONS
+++++++++++++++++++
+++++
=====
```

WALL BOUNDARY CONDITION SETUP
(DIMENSIONLESS)

DATA SET FOR THE WALL BOUNDARY CONDITIONS

First set of wall boundary conditions (applied to the walls of the channel) :

imposed temperature : Tc

&Heat_Wall_Boundary_Condition_Setup
 Wall_BC_DataSetName ="Set1",
 West_Heat_BC_Option = 0 , East_Heat_BC_Option = 0 ,
 Back_Heat_BC_Option = 0 , Front_Heat_BC_Option = 0 ,
 West_Wall_BC_Value= 1.0 , East_Wall_BC_Value= 1.0 ,
 Back_Wall_BC_Value= 1.0 , Front_Wall_BC_Value= 1.0 /

The usual wall boundary conditions for the velocity are used (no-slip and impermeability conditions).

As they are the conditions by default, they are not explicitly written

Second set of wall boundary conditions (applied to the walls of the square bar) :

imposed temperature : Th

&Heat_Wall_Boundary_Condition_Setup
 Wall_BC_DataSetName ="Set2",
 West_Heat_BC_Option = 0 , East_Heat_BC_Option = 0 ,
 Back_Heat_BC_Option = 0 , Front_Heat_BC_Option = 0 ,
 West_Wall_BC_Value= 2.0 , East_Wall_BC_Value= 2.0 ,
 Back_Wall_BC_Value= 2.0 , Front_Wall_BC_Value= 2.0 /

The usual wall boundary conditions for the velocity are used (no-slip and impermeability conditions).

As they are the conditions by default, they are not explicitly written

INLET AND OUTLET BOUNDARY CONDITIONS
(DIMENSIONLESS)

Keep in mind that the domain is enclosed by default.

Here the inlet and outlet conditions are located at the ends of the domain. They replace the walls by default over the interested areas.

Inlet : Uniform flowrate profil

```
&Inlet_Boundary_Conditions Type_of_BC= "INLET", Direction_Normal_Plan= 1 , Flow_Direction= 1 ,
                                Plan_Location_Coordinate= 0.0      ,
                                Start_Coordinate_of_First_Span = 0.00   ,
End_Coordinate_of_First_Span = 1.00 ,
                                Start_Coordinate_of_Second_Span= 0.0      ,
End_Coordinate_of_Second_Span= 0.0      ,
                                Normal_Velocity_Reference_Value= 1.0      ,
                                Temperature_Reference_Value= 1.0 /

&Outlet_Boundary_Conditions Type_of_BC= "OUTLET",
Direction_Normal_Plan= 1 , Flow_Direction= 1 ,
                                Plan_Location_Coordinate= 10.0     ,
                                Start_Coordinate_of_First_Span = 0.00   ,
End_Coordinate_of_First_Span = 1.00 ,
                                Start_Coordinate_of_Second_Span= 0.0      ,
End_Coordinate_of_Second_Span= 0.0 /
=====
=====

                BORDER BOUNDARY CONDITIONS
=====

!--- No new boundary conditions are defined at the ends of the domain :
walls by default are preserved, the inlet and outlet previously are
defined above)
!--- As "None" is the default setting for this namelist, it can be
removed

&Border_Domain_Boundary_Conditions West_BC_Name= "None" , East_BC_Name=
"None" , Back_BC_Name= "None" , Front_BC_Name= "None" , North_BC_Name=
"None" , South_BC_Name= "None" /
+++++
=====

                NUMERICAL METHODS
=====

&Numerical_Methods NS_NumericalMethod= "BDF2-Scheme02"
,           !--- BDF2 + 2nd order centered scheme
            MomentumConvection_Scheme="Centered-02-
Conservative" ,           !--- conservative form for solving the velocity
(momentum) equation
            Poisson_NumericalMethod="Home-SORMultigrid-
ConstantMatrixCoef" / !--- SOR + multigrid method (homemade release)
for solving the Poisson's equation with constant coefficient matrix

&HomeData_PoissonSolver SolverName="SOR" ,           !---
Successive Over-Relaxation (SOR) method based on the red-black
algorithm
```

```

                    Relaxation_Coefficient= 1.7 ,           !---
Relaxation coefficient of the SOR method ( 1 <= Relaxation_Coefficient
< 2)                                         Number_max_Grid= 4,           !---
Number of grid levels                         Number_max_Cycle= 10,          !---
Number of multigrid cycles                   Number_Iteration= 0,          !---
Maximum number of SOR iterations method applied for any grid level, if
0 (or removed) the 3 next data are considered
                                         Number_Iteration_FineToCoarseGrid= 15, !---
number of SOR iterations applied on any grid level during the
restriction step (before the coarsest grid computation)
                                         Number_Iteration_CoarseToFineGrid= 15, !---
number of SOR iterations applied on any grid level during the
prolongation step (after the Coarsest grid computation)
                                         Number_Iteration_CoarsestGrid= 15 ,   !---
number of SOR iterations applied on the coarsest grid
                                         Convergence_Criterion= 1.D-08 /      !---
convergence tolerance on the residu of the Poisson's equation
+++++
+++++

```

SIMULATION MANAGEMENT

```

+++++
+++++
The numerical time step is imposed

&Simulation_Management    Restart_Parameter= 0 ,
                           Steady_Flow_Stopping_Criterion_Enabled =
                           .true. , Steady_Flow_Stopping_Criterion = 1.D-16,
                           Temporal_Iterations_Number = 100000
                           , Final_Time = 5.D+00 ,           TimeStep_Type = 0 ,
                           Timestep_Max = 1.D-03 ,
                           Simulation_Backup_Rate           = 1000
                           , Simulation_Checking_Rate = 101 /
=====
```

PROBES MANAGEMENT

```

=====
=====

Probes order     U
, V      , W      , T      , P      , RHO
&Probe_Quantities_Enabled  Temporal_Series_For_Quality_Enabled(:) =
                           .true., .true., .false., .false., .true. , .false. /
&Probe_Location  Xi= 3.0 , Xj= 0.5 , Xk= 0.0 /
&Probe_Location  Xi= 6.0 , Xj= 0.5 , Xk= 0.0 /
&Simulation_Management Probe_TimeIterationRecordingRate= 10 ,
                           Probe_StartTimeIterationRecording= 0 ,
```

```
Probe_RecordingReset=.false. /  
  
=====  
===== FIELDS RECORDING SETUP  
=====  
&Field_Recording_Setup      Precision_On_Instantaneous_Fields= 2 /  
  
!--- Snapshots  
  
&Simulation_Management  
  InstantaneousFields_RecordingReset=.false. ,  
  InstantaneousFields_TimeRecordingRate= 5.0E-01 ,  
  InstantaneousFields_RecordingStartTime= 0.D-00 /  
  
&Instantaneous_Fields_Listing  Name_of_Field = "U" / First  
velocity component  
&Instantaneous_Fields_Listing  Name_of_Field = "V" / Second  
velocity component  
&Instantaneous_Fields_Listing  Name_of_Field = "T" /  
Temperature  
  
!--- Statistics  
  
&Simulation_Management      Start_Time_For_Statistics= 1.D+03  
, Time_Range_Statistic_Calculation = 5.D+00 /  
  
&Statistical_Fields_Listing  Name_of_Field = "<U>" /  
&Statistical_Fields_Listing  Name_of_Field = "<V>" /  
  
END OF FILE
```

[Click here to come back to the previous page](#)

From:
<https://sunfluidh.lisn.upsaclay.fr/> - Documentation du code de simulation numérique SUNFLUIDH

Permanent link:
https://sunfluidh.lisn.upsaclay.fr/doku.php?id=sunfluidh:2d_channel_flow_with_heated_bar_incomp_flow

Last update: **2019/11/13 16:32**

