


```

=====
====
                                GRAVITY
                                (DIMENSIONLESS FORM)
=====
====
&Gravity Gravity_Enabled= .true. , Gravity_Angle_IJ= 90.0 ,
Gravity_Angle_IK= 90.0 , Reference_Gravity_Constant= 0.71/
=====
====
                                DOMAIN FEATURES
=====
====
&Domain_Features Start_Coordinate_I_Direction= 0.00 ,
End_Coordinate_I_Direction= 1.00,
                                Start_Coordinate_J_Direction= 0.00 ,
End_Coordinate_J_Direction= 1.00,
                                Start_Coordinate_K_Direction= 0.00 ,
End_Coordinate_K_Direction= 0.00,
                                Cells_Number_I_Direction= 64
,Cells_Number_J_Direction=64 ,Cells_Number_K_Direction= 1,
                                Regular_Mesh= .true. /

+++++
+++++
DEFINITION OF BOUNDARY CONDITIONS
+++++
+++++
=====
=====
WALL BOUNDARY CONDITION SETUP
=====
=====
Keep in mind that the domain is enclosed by default.
No new boundary conditions are defined at the ends of the domain : the
walls by default are preserved

&Heat_Wall_Boundary_Condition_Setup
    Wall_BC_DataSetName = "Set1",
    West_Heat_BC_Option = 0 , East_Heat_BC_Option = 0 ,
    Back_Heat_BC_Option = 1 , Front_Heat_BC_Option = 1 ,
    South_Heat_BC_Option = 0 , North_Heat_BC_Option = 0,
    West_Wall_BC_Value= 1.0 , East_Wall_BC_Value= 0.0 ,
    Back_Wall_BC_Value= 0.0 , Front_Wall_BC_Value= 0.0 ,
    South_Wall_BC_Value= 0.0 , North_Wall_BC_Value= 0.0 /

=====
=====
BORDER BOUNDARY CONDITIONS : The walls located by default at the ends

```

of the domain remain unchanged

=====
=====

!--- No new boundary conditions are defined at the ends of the domain : walls by default are preserved, the inlet and outlet previously are defined above)

!--- As "None" is the default setting for this namelist, it can be removed

&Border_Domain_Boundary_Conditions West_BC_Name= "None" , East_BC_Name= "None" , Back_BC_Name= "None" , Front_BC_Name= "None" , North_BC_Name= "None" , South_BC_Name= "None" /

++++++
++++++

NUMERICAL METHODS

++++++
++++++

&Numerical_Methods NS_NumericalMethod= "BDF2-Scheme02"
, !--- BDF2 + 2nd order centered scheme
MomentumConvection_Scheme="Centered-02-Conservative" , !--- conservative form for solving the velocity (momentum) equation
Poisson_NumericalMethod="Home-SORMultigrid-ConstantMatrixCoef" / !--- SOR + multigrid method (homemade release) for solving the Poisson's equation with constant coefficient matrix

&HomeData_PoissonSolver SolverName="SOR" , !---
Successive Over-Relaxation (SOR) method based on the red-black algorithm

Relaxation_Coefficient= 1.7 , !---
Relaxation coefficient of the SOR method (1 <= Relaxation_Coefficient < 2)

Number_max_Grid= 5, !---
Number of grid levels

Number_max_Cycle= 10, !---
Number of multigrid cycles

Number_Iteration= 0, !---
Maximum number of SOR iterations method applied for any grid level, if 0 (or removed) the 3 next data are considered

Number_Iteration_FineToCoarseGrid= 3, !---
number of SOR iterations applied on any grid level during the restriction step (before the coarsest grid computation)

Number_Iteration_CoarseToFineGrid= 15, !---
number of SOR iterations applied on any grid level during the prolongation step (after the Coarsest grid computation)

Number_Iteration_CoarsestGrid= 15 , !---
number of SOR iterations applied on the coarsest grid

Convergence_Criterion= 1.D-08 / !---
convergence tolerance on the residu of the Poisson's equation

```

+++++
+++++
SIMULATION MANAGEMENT
+++++
+++++

```

The numerical time step is estimated by means of the CFL coefficient

```

&Simulation_Management  Restart_Parameter= 0 ,
                        Steady_Flow_Stopping_Criterion_Enabled =
.true. , Steady_Flow_Stopping_Criterion = 1.D-16,
                        Temporal_Iterations_Number = 1000000
, Final_Time = 5.D+02 ,
                        TimeStep_Type = 1 ,
                        Timestep_Min = 1.D-02
, Timestep_Max = 1.D-02 ,
                        CFL_Min      = 0.5
, CFL_Max      = 0.5 ,
                        Iterations_For_Timestep_Linear_Progress= 1,
                        Simulation_Backup_Rate      =
1000 , Simulation_Checking_Rate = 101 /

```

```

=====
=====
PROBES MANAGEMENT
=====
=====

```

NO PROBE

```

=====
=====
FIELDS RECORDING DECLARATION
=====
=====

```

```

&Simulation_Management  Fields_Recording_Rate = 5.D+01 /
&Field_Recording_Setup   Check_Special_Features=
"Heat_Driven_Cavity_Flow", Precision_On_Instantaneous_Fields= 2 /
Here, a special variable devoted to results of heat driven cavity flows
is active

```

```

&Instantaneous_Fields_Listing  Name_of_Field = "U      " ,
Recording_Enabled = .true. /      First velocity component
&Instantaneous_Fields_Listing  Name_of_Field = "V      " ,
Recording_Enabled = .true. /      Second velocity component
&Instantaneous_Fields_Listing  Name_of_Field = "T      " ,
Recording_Enabled = .true. /      Temperature

```

END OF FILE

Last
update: 2018/12/15 sunfluidh:2d_heat_driven_cavity_incomp_flow https://sunfluidh.lisn.upsaclay.fr/doku.php?id=sunfluidh:2d_heat_driven_cavity_incomp_flow&rev=1544878723
13:58

[Click here to come back to the previous page](#)

From:

<https://sunfluidh.lisn.upsaclay.fr/> - **Documentation du code de simulation numérique SUNFLUIDH**

Permanent link:

https://sunfluidh.lisn.upsaclay.fr/doku.php?id=sunfluidh:2d_heat_driven_cavity_incomp_flow&rev=1544878723

Last update: **2018/12/15 13:58**

