

# Geometric series "Type 2"

## Description

The function is based on a geometric series where some of input parameters can be modified in order to attempt to keep a geometric distribution.

[Click here to come back to the previous page](#)

---

## Namelist :

```
&MESH_FUNCTION_DATA  Function_Name="GEOMETRIC_SERIE_2",  
                      Number_of_Cells= 32           ,  
                      Length= 1.0                   ,  
                      Left_Cell_Size= 2.0d-02       ,  
                      Right_Cell_Size= 5.0d-02      ,  
                      Reverse_Ordering= .false. /
```


## Principle :

Here, the Left\_Cell\_Size and Right\_Cell\_Size are associated to the minimum and maximum cell sizes at the tips.

The cell size distribution  $h(l)$  is computed by estimation of the cell ratio in regard to the length, The Minimum cell size (Left\_Cell\_Size), the maximum cell size (Right\_Cell\_Size) and the cell number (Number\_of\_Cells).

The procedure is recursive and **different parameters can be adjusted** at each step in order to find the best compromise.

It can be relevant to check the data after computing.



[Click here to come back to the previous page](#)

From:  
<https://sunfluidh.lisn.upsaclay.fr/> - **Documentation du code de simulation numérique SUNFLUIDH**

Permanent link:  
[https://sunfluidh.lisn.upsaclay.fr/doku.php?id=sunfluidh:geom2\\_meshgen](https://sunfluidh.lisn.upsaclay.fr/doku.php?id=sunfluidh:geom2_meshgen)

Last update: **2017/12/03 16:49**

