

The old version of file vifield_s.dat is composed with 12 line of integer values. This version is still available for people used to the old version of VISFIELD.

- The first two lines allows the user to select a series of files should be converted. The first line is associated to the subdomain number and the second line to the file number which are included in the file name.
- The following line contains one integer value which defines the type of file to convert
 - 0 : instantaneous fields : res_yyyy_xxxxxxx.d
 - 1 : statistical fields : rst_yyyy_xxxxxxx.d
- The three following lines are associated to the grid indices of the computational domain. These index set allows the user to build a space box for extracting only a part of fields from the computational domain.
If one of these index values is set to zero, the whole domain is considered regardless of the meshsize, including the ghost cells.
- The following line contains just one integer value for selecting the type of format in which the file will be converted.
0 : tecplot format (.plt) - 1 : VTK format (.vtk).
- The following line is a peculiar data related to the vtk format conversion. An integer data defines if the vtk data must be written as a rectilinear form (value 0) or a structured-grid form (value 1).
- The three last lines are reserved to the special case of data manipulation : Please, do not consider them for your work and do not modify them.

[visfield_s.dat](#)

```

00000 1 !--- 1st subdomain number and total number of subdomains for
file selection (related to the 1st number in the file name)
0 200 1 !--- 1st file number, last file number and file number-step
for file selection (related to the 2nd number in the file name)
0           !--- Type of file to convert (0 : instantaneous fields, 1:
statistical fields)
0 130     !--- Start and end indices along the I-direction | => space
box for considering only a part of fields
1 130     !--- Start and end indices along the J-direction |   a zero
value indicates the whole computational domain is considered
1 130     !--- Start and end indices along the K-direction |
1           !--- selection of the format conversion -> 0 : tecplot format
(.plt) - 1 : VTK format (.vtk)
0           ! Only for VTK format -> 0 : rectilinear form , 1: structured
grid form
rst_00000_0000001.d !--- special data. Do not modify it.
3                   !--- special data. Do not modify it.
1 3                 !--- special data. Do not modify them.
EOF

```

The new version of file, visfield_sunfluidh.dat, allows you to use much more functionalities of VISFIELD, like slice reading. Data setup is organised with the concept of Namelist. All possibilites are described in the example provided here.

[visfield_sunfluidh.dat](#)

```
=====
```

Data parameters for converting the SUNFLUIDH binary files to Tecplot or VTK format

New data file for the new release of VISFIELD

```
=====
```

Domain decomposition (MPI simulation)

Number of subdomains along each direction (I,J and K)
for a simulation performed with a domain decomposition approach (MPI)
If MergingData_Enabled=.true., all subdomain fields are grouped in a same Tecplot or VTK file

```
&DomainDecompositionFeatures NumberOfSubdomains_Idir= 1,  
                                NumberOfSubdomains_Jdir= 1,  
                                NumberOfSubdomains_Kdir= 1,  
                                MergingData_Enabled=.false. /
```

File parameters

Define the features of the file to convert

```
TypeOfData ='snapshots'      --> instantaneous fields  
: files res_xxxxx_yyyyyyy.d  
TypeOfData ='block_snapshots' --> instantaneous fields on specified  
blocks : files res_xxxxx_yyyyyyy.d  
TypeOfData ='stastistics'     --> statistics fields  
: files rst_xxxxx_yyyyyyy.d
```

```
TypeOfData ='slices'           --> fields on slices
: files slice_sn_d_xxxxx_yyyyyyy.d

Special data :

TypeOfData ='space_averaged_snapshots'      --> space averaged
snapshots along a direction : files spav_plan_d_yyyyyyy.d

Default parameters implicitly imposed :
MergingData_Enabled= .false. (data already gathered in a unic file)
                                         Any parameter
related to the domain decomposition is set such as only one domain is
considered

with :
        xxxx : rank of subdomain (MPI process)
        yyyy : number associated to the time recording of data
        d    : this number indicates the orientation of the plan
(automatically considered by the VISFIELD)
        sn    : rank of the plane (rank in the SUNFLUIDH data
file)

        FirstSubdomainRank = xxxx : first subdomain rank for
files to convert
        NumberOfSubdomains = xxxx : Number of subdomains to
consider from FirstSubdomainRank
        SubdomainsStride          : Stride on subdomain ranks
        FirstRecordingIndex = yyyy : first time recording value
for files to convert
        LastRecordingIndex = yyyy : last time recording value for
files to convert
        IndexStride               : stride on time recording
value
        FirstSlice_ID= sn        : Value of the first rank for 'slices'
data files to convert
        LastSlice_ID = sn        : Value of the last rank for 'slices'
data files to convert
        FirstBlock_ID= sn        : Value of the first rank for
'block_snapshots' data files to convert
        LastBlock_ID = sn        : Value of the last rank for
'block_snapshotss' data files to convert

Notes : - By default SubdomainsStride and IndexStride are set to 1
       - By default NumberOfSubdomains = NumberOfSubdomains_Idir *
NumberOfSubdomains_Jdir* NumberOfSubdomains_Kdir
       - When 'slices' is selected, FirstSubdomainRank must be the
lowest MPI rank in which the plane is defined.
                                         when MergingData_Enabled= .true. :
NumberOfSubdomains is automatically updated by
VISFIELD in regard to NumberOfSubdomains_Idir, NumberOfSubdomains_Jdir
and NumberOfSubdomains_Kdir
```

```
when MergingData_Enabled= .false.  
: NumberofSubdomains must take into account all the MPI rank covering  
the plane  
(NumberofSubdomains= FirstSubdomainRank + the highest MPI rank in which  
the plane is defined)  
If a file selected by VISFIELD is  
not present in the work directory, it is ignored  
- When 'snapshots' or 'statistics' is selected,  
NumberofSubdomains can be ignored if NumberofSubdomains_Idir,  
NumberofSubdomains_Jdir, NumberofSubdomains_Kdir are correctly set.  
All subdomain  
will be considered if FirstSubdomainRank= 0  
if the user  
want only convert some subdomain files, he may plays with  
FirstSubdomainRank, NumberofSubdomains, SubdomainsStride  
- When 'space_averaged_snapshots' is selected,  
MergingData_Enabled= .false. . Data are automatically regrouped in a  
single file  
If a file selected by VISFIELD is  
not present in the work directory, it is ignored  
  
&DataFileFeatures TypeOfData="statistics",  
FirstRecordingIndex=1 ,  
LastRecordingIndex= 1 ,  
IndexStride= 1 /  
  
!DataFileFeatures TypeOfData="snapshots",  
FirstRecordingIndex=1 ,  
LastRecordingIndex= 5,  
IndexStride= 1 /  
  
!DataFileFeatures TypeOfData="block_snapshots",  
FirstRecordingIndex=1 ,  
LastRecordingIndex= 10,  
IndexStride= 1  
FirstBlock_ID=1,  
LastBlock_ID=1 /  
  
!DataFileFeatures TypeOfData="slices",  
FirstRecordingIndex= 1 ,  
LastRecordingIndex= 10,  
FirstSubdomainRank = 0,  
NumberofSubdomains= 1,  
FirstSlice_ID=1,  
LastSlice_ID=1,  
IndexStride= 1 /
```

```
!DataFileFeatures TypeOfData="space_averaged_snapshots",
FirstRecordingIndex=1 ,
LastRecordingIndex= 40 /
-----
-----  
Format conversion  
-----  
-----  
VelocityCylindricalCoordinates= .True. In cylindrical geometry, the  
coordinates are converted to cartesian geometry while the velocity  
components leave in cylindrical geometry  
else (false) they also converted  
TecplotFormat_Enabled= .true. Binary data are converted to Tecplot  
data  
VTKFormat_Enabled = .true. Binary data are converted to Legacy VTK  
data  
  
&DataFormat VelocityCylindricalCoordinates=.False.,
TecplotFormat_Enabled = .True. /
!VTKFormat_Enabled= .true. /
-----  
-----  
Special case : Extract field fluctuations from snapshots and  
statistics data  
RESTRICTED USE !!!!  
-----  
-----  
&ExtractFluctuations_Special/ ExtractFluctuations_Enabled= .false. ,
NumberOffFields= 1,
StatisticsFileName='rst_00000_0000001.d' /
```

[Click here to come back to the previous page](#)

From:

<https://sunfluidh.lisn.upsaclay.fr/> - Documentation du code de simulation numérique SUNFLUIDH

Permanent link:

https://sunfluidh.lisn.upsaclay.fr/doku.php?id=sunfluidh:visfield_sunfluidh_file&rev=1560871618

Last update: 2019/06/18 17:26

